ADATTATORE DA VIAGGIO UNIVERSALE

ISTRUZIONI E SICUREZZA, LEGGERE LE ISTRUZIONI PRIMA DELL'USO

L'adattatore da viaggio è adatto all'uso con la maggior parte dei dispositivi elettronici con spine a 2 poli, di classe II fino a 2,5A (110V max 275W: 220V max 550W). Collega i tuoi dispositivi portatili senza messa a terra in tutto il mondo.

ATTENZIONE

- Non utilizzare con spine con messa a terra.
  Il modulo multi-adattatore non converte la tensione elettrica. Per la conversione di tensione è necessario un convertitore o trasformatore.
- Controllare sempre la tensione nominale del dispositivo portatile prima dell'uso. La tensione di ingresso del dispositivo che si desidera collegare deve corrispondere alla tensione della rete elettrica locale. In caso di dubbi, consultare un esperto locale.
- Se il dispositivo portatile è SINGOLO, potrebbe essere necessario un convertitore o un trasformatore in un paese straniero.
- I dispositivi a doppia tensione possono essere utilizzati con questo adattatore se non superano i limiti.
- Utilizzare solo con una serie di spine estese per evitare il rischio di scosse elettriche. Non forzare l'estensione di più di una serie di punte in quanto ciò può causare danni al meccanismo interno e all'apparecchio e può provocare rischi di incendio, scosse elettriche o lesioni personali.
- Solo per uso interno.
- Non tentare di utilizzare un dispositivo da 110V CA in una presa da 220/240V CA se il dispositivo non dispone di una funzione a doppia tensione.
- È necessario collegare un solo dispositivo portatile alla volta all'adattatore.
- Non utilizzare mai una prolunga con un adattatore. Non utilizzare mai in combinazione con un altro adattatore.
- Scollegare l'adattatore dalla presa del circuito elettrico quando non lo si utilizza per ridurre il rischio di scosse elettriche o incendi.
- Non utilizzare questo adattatore con prodotti per lampade contenenti portalampade (prese) con base a vite
- Collegare sempre prima la spina dell'adattatore al dispositivo portatile, quindi inserirlo nella presa.
- Solo per dispositivi a doppia tensione: prima di inserire, impostare l'interruttore del dispositivo portatile sulla stessa tensione della presa a muro esterna prima dell'uso.
- Non utilizzare l'adattatore se l'alloggiamento è danneggiato.
- Rischio di scosse elettriche o incendio. Non esporre l'adattatore a nessun tipo di liquido o umidità.
- Non sostituire questo gruppo spina.

IMPORTANTE! CONSERVARE QUESTE ISTRUZIONI
Non utilizzare con dispositivi con potenze superiori a 275W 110V CA o 550W 220V CA.

PRECAUZIONI DI SICUREZZA:

1. Non lasciare l'unità incustodita durante l'uso. Scollegare immediatamente dopo uso.
2. Seguire le istruzioni del produttore del dispositivo portatile per un funzionamento sicuro.
3. Se l'unità adattatore non funziona correttamente, NON UTILIZZARE.
4. Assicurarsi di controllare la tensione e la potenza del dispositivo portatile e le impostazioni e l'impostazione della potenza prima dell'uso.
5. Tenere lontano da superfici riscaldate.
6. Solo per uso interno.
7. Usare solo temporaneamente in derivazione da prese fisse; in caso di impieghi permanenti sostituire la presa con una adatta agli apparecchi da alimentare.
8. Questa apparecchiatura non è adatta all'uso in locali nei quali è probabile la presenza di bambini.

Panoramica del prodotto e funzioni di base:
Prese adattatrici universali compatte per le prese a muro nei paesi più visitati

- Australia / Nuova Zelanda / Cina / Figi
- Regno Unito / Irlanda / Africa / Hong Kong / Singapore
- Europa / Medio Oriente / alcuni africani, asiatici e Paesi caraibici
- Nord e Sud America / Giappone / Caraibi

Modulo adattatore multiplo:

- Compatibile con la maggior parte degli apparecchi da viaggio / convertitori / trasformatori di potenza statunitensi, britannici ed europei
- 100-240 V CA, 50-60 Hz, max.

Come utilizzare la spina dell'adattatore da viaggio
Collegare il modulo superiore alla parte superiore dell'unità base fino a quando non scatta in posizione.

ILLUSTRAZIONE 1




ILLUSTRAZIONE 2




ILLUSTRAZIONE 3




Utilizzo dell'adattatore da viaggio:

• Agganciare il normale modulo spina multi-adattatore sull'adattatore base.
• Prima dell'uso, premi il pulsante di sblocco (Vedi figura 1) e sposta tutti i cursori di selezione sul lato delle loro posizioni iniziali. (Vedi figura 2)
• Inserire la spina del dispositivo portatile nella presa del modulo spina multi-adattatore appropriata
• Selezionare il cursore della spina dell'adattatore sul pannello laterale appropriato per la presa del paese in cui ci si trova. (Vedi figura 3)
• Premere il pulsante di sblocco e contemporaneamente scorrere il cursore di selezione necessario in avanti fino a quando non scatta in posizione.
• Inserire l'adattatore nella presa a muro e accendere il dispositivo portatile.
• Dopo l'uso, spegnere il dispositivo portatile, rimuovere l'adattatore dalla presa a muro e scollegare il dispositivo portatile dal modulo multi-adattatore.
• Premere il pulsante di sblocco e contemporaneamente far scorrere in avanti il selettore della spina desiderata fino a quando non scatta in posizione.
• Inserire l'adattatore nella presa a muro e accendere il dispositivo portatile.
• Dopo l'uso, spegnere il dispositivo portatile, rimuovere l'adattatore dalla presa a muro e scollegare il dispositivo portatile dal modulo multi-adattatore.
• Premere il pulsante di sblocco per rimuovere il modulo Plug superiore dall'unità base.

IMPORTANTE!
Prima di spostare qualsiasi selettore in avanti TUTTI i selettori devono essere in posizione arretrata.
Premere il pulsante di sblocco e spostare tutte le diapositive del selettore all'indietro nella posizione originale.
(Illustrazione 3)

ILLUSTRAZIONE 4



Spine specifiche per Paese
PER SELEZIONARE UN TIPO DI SPINA SPECIFICA PER PAESE CORRETTO:
• SPINA EUROPEA
• SPINA AUSTRALIA
• SPINA REGNO UNITO
• SPINA USA
Premere il pulsante di sblocco sul lato dell'unità base. Far scorrere il selettore in avanti fino a quando la spina specifica del paese appropriato si estende e scatta in posizione.

ATTENZIONE
Per ridurre il rischio di incendi o scosse elettriche, utilizzare solo con questi tipi di spina:
SPINA EUROPEA: 220 V CA (2 pin rotondi)
Albania, Angolo, Argentina, Austria, Azzorre, Isole Baleari, Bangladesh, Belgio, Bolivia, Bosnia, Brasile, Bulgaria, Burkina Faso, Burundi, Camerun, Isole Canarie, Capo Verde, Repubblica
Centrafricana. Isole del Canale. Cile. Comore. Congo. Croazia. Repubblica Democratica del Congo. (Zaire) Costa d'Avorio. Cipro. Danimarca. Gibuti. Egitto. El Salvador. Guinea Equatoriale. Eritrea, Isole Faer Der, Finlandia, Francia, Gabon, Germania, Gibilterra, Grecia, Groenlandia, Guadalupa, Guinea, Guinea-Bissau, Ungheria, Islanda, India, Indonesia, Iran, Iraq, Israele, Italia, Kazakistan, Corea, Kuwait, Laos, Libano, Lituania, Lussemburgo, Macedonia, Madagascar, Madera, Mali, Martinica, Mauritania, Mauritius, Monaco, Marocco, Mozambico, Myanmar, Nepal, Paesi Bassi, Niger, Norvegia, Oman, Pakistan, Paraguay, Perù, Filippine, Polonia, Portogallo, Romania, Russia, Ruanda, San Vincenzo, Senegal, Somalia, Spagna, Sudan, Suriname, Svezia, Svizzera, Siria, Tailandia, Togo, Tunisia, Turchia, Uruguay, Vietnam, Jugoslavia (ex), Zambia.

SPINA AUSTRALIA: 110V CA (2 pin angolati)

Samoa americane, Argentina, Australia, Cina, El Salvador, Figi, Guatemala, Kiribati, Nauru, Nuova Zelanda, Okinawa, Panama, Papua, Nuova Guinea, San Vincenzo, Tagikistan, Tonga, Uruguay.

SPINA USA: 110 V CA (2 pin piatti paralleli)

Samoa americane, Anguilla, Antigua, Aruba, Bahamas, Bangladesh, Barbados, Bermuda, Bolivia, Brasile, Cambogia, Canada, Isole Cayman, Cina (senza fori nelle lame e lame leggermente più corte], Colombia, Costa Rica, Cuba, Ecuador, El Salvador, Guam, Guatemala, Guyana, Haiti, Honduras, Giamaica, Giappone, Laos, Libano, Liberia, Maldive, Messico, Micronesia, Montserrat, Paesi Bassi, Antille, Nicaragua, Niger, Okinawa, Panama, Perù, Filippine, Porto Rico, Saint Vincent, Arabia Saudita, Tahiti, Taiwan, Tailandia, Stati Uniti, Venezuela, Vietnam,

Isole Vergini (USA e Britanniche), Yemen.

SPINA DEL REGNO UNITO: 220 V CA (3 pin quadrati)

Bahrein, Bangladesh, Belize, Botswana, Brunei, Camerun, Isole del Canale, Cina, Cipro, Dominica, El Salvador, Gambia, Ghana, Gibilterra, Grenada, Guatemala, Guyana, Hong Kong, Iraq, Irlanda,


Isola di Man, Giordania, Kuwait, Libano, Macao,

Malesia, Maldive, Malta, Mauritius, Myanmar, Nigeria, Oman, Qatar, St. Kitts-Nevis, St Lucia, St Vincent, Arabia Saudita, Seychelles, Sierra Leone, Singapore, Tanzania, Uganda, Emirati Arabi Uniti, Regno Unito, Vietnam, Yemen, Zambia, Zimbabwe.

Per chiudere l'adattatore nella posizione originale:
premere il pulsante e, allo stesso tempo, far scorrere il Selettore di scorrimento completamente nella posizione originale in modo che la spina dell'adattatore sia incassata nella base dell'unità.

Scomparto fusibili di ricambio:
l'unità utilizza solo fusibili T2.5A. Utilizzare una moneta o un oggetto simile per svitare il coperchio del vano. Sostituire il fusibile, rimettere il coperchio e riavvitare saldamente in posizione (illustrazione 5).

ILLUSTRAZIONE 5



Il dispositivo è conforme alla Parte 15 delle norme FCC. Il funzionamento è soggetto alle due seguenti condizioni:
(1) questo dispositivo non può causare interferenze dannose e
(2) questo dispositivo può accettare qualsiasi interferenza
Manomissioni o modifiche non espressamente approvate da parte del costruttore annullano la conformità del prodotto e l'autorizzazione all'utente ad utilizzare il prodotto.

Garanzia

La garanzia si applica quando il prodotto viene utilizzato in condizioni normali per le quali è stato progettato. Questa garanzia non copre danni accidentali, uso irragionevole o improprio, normale usura, manipolazione impropria o danni causati da un corriere comune, perdita di utilizzo o danni consequenziali, né copre le riparazioni tentate da persone non autorizzate.

Questo simbolo indica che, alla fine della sua vita utile, il prodotto non deve essere smaltito assieme ai rifiuti domestici (Rif. Direttiva 2012/19/UE).
Può essere consegnato presso i centri di raccolta differenziata, seguendo le regole del proprio paese, oppure riconsegnato al distributore all'atto dell'acquisto di un nuovo apparecchio. Il corretto smaltimento di questo prodotto aiuta a prevenire l'inquinamento dell'ambiente e possibili danni alla salute.

Il prodotto è conforme ai requisiti essenziali ed alle altre disposizioni applicabili stabilite dalla direttiva

Il dispositivo è protetto da doppio isolamento o isolamento rinforzato.

Il prodotto deve essere utilizzato e funzionare solo in ambienti interni chiusi e asciutti. Il prodotto non deve diventare umido o bagnato, altrimenti esiste il rischio di scosse elettriche mortali!

UNIVERSAL TRAVEL ADAPTER
INSTRUCTIONS AND SAFETY INFORMATION – PLEASE READ BEFORE USE

This travel adapter is suitable for most electronic devices with 2-pole, Class II plugs up to 2.5A (max. 275W at 110V / max. 550W at 220V). Allows non-grounded portable devices to be connected worldwide.

WARNING

- Do not use with grounded plugs.
- This adapter does not convert voltage. A voltage converter or transformer is required for voltage conversion.
- Always check the rated voltage of the portable device before use. The input voltage of the device you wish to connect must match the local electrical supply. If in doubt, consult a local expert.
- If the portable device is single voltage, you may need a converter or transformer when traveling abroad.
- Dual voltage devices may be used with this adapter if they do not exceed the limits.
- Use only with one set of extended plug pins to avoid the risk of electric shock. Do not force out more than one set of pins at once, as this may damage the internal mechanism and the appliance, and may result in fire, electric shock, or personal injury.
- For indoor use only.
- Do not attempt to use a 110V AC device in a 220/240V AC outlet if the device does not support dual voltage.
- Only one portable device should be connected to the adapter at a time.
- Never use an extension cord with the adapter. Never use in combination with another adapter.
- Unplug the adapter from the wall outlet when not in use to reduce the risk of electric shock or fire.
- Do not use this adapter with lighting products that have screw-type lamp holders (sockets).
- Always connect the adapter plug to the portable device first, then insert it into the wall socket.
- For dual-voltage devices only: before plugging in, set the portable device switch to match the wall outlet voltage before use.
- Do not use the adapter if the casing is damaged.
- Risk of electric shock or fire. Do not expose the adapter to any liquids or moisture.
- Do not replace or modify this plug unit.

IMPORTANT! KEEP THESE INSTRUCTIONS

Do not use with devices exceeding 275W at 110V AC or 550W at 220V AC.

SAFETY PRECAUTIONS:

1. Do not leave the unit unattended while in use. Always unplug the unit after use.
2. Follow the portable device manufacturer's instructions for safe operation.
3. If the adapter unit is not working properly, DO NOT USE.
4. Make sure to check the voltage and wattage of the portable device and power settings before use.
5. Keep away from heated surfaces.
6. For indoor use only.
7. Use only as a temporary solution with fixed wall outlets. For permanent setups, consult an electrician to install a suitable outlet.
8. This device is not suitable for use in locations where children are likely to be present.

Product Overview and Basic Functions:

Compact universal adapter plugs for wall sockets in the most frequently visited countries:

- Australia / New Zealand / China / Fiji
- United Kingdom / Ireland / Africa / Hong Kong / Singapore
- Europe / Middle East / some African, Asian, and Caribbean countries
- North and South America / Japan / Caribbean

Multi-Adapter Module:

- Compatible with most U.S., U.K., and European travel appliances / converters / power transformers
- 100–240V AC, 50–60Hz, max.

How to Use the Travel Adapter Plug:

Attach the top module to the top of the base unit until it clicks into place.

ILLUSTRATION 1




ILLUSTRATION 2




ILLUSTRATION 3




Using the Travel Adapter:

- Attach the standard multi-adapter plug module to the base adapter.
- Before use, press the release button (See Figure 1) and move all the selection sliders to the side of their initial positions. (See Figure 2)
- Insert the portable device's plug into the appropriate socket of the multi-adapter plug module.
- Select the plug slider on the appropriate side panel for the socket type used in the country you are in. (See Figure 3)
- Press the release button and simultaneously slide the required plug selector forward until it clicks into place.
- Insert the adapter into the wall socket and turn on the portable device.
- After use, turn off the portable device, remove the adapter from the wall socket, and disconnect the portable device from the multi-adapter module.
- Press the release button and simultaneously slide the desired plug selector forward until it clicks into place.
- Insert the adapter into the wall socket and turn on the portable device.
- After use, turn off the portable device, remove the adapter from the wall socket, and disconnect the portable device from the multi-adapter module.
- Press the release button to remove the upper plug module from the base unit.

IMPORTANT!

Before sliding any selector forward, **ALL selectors must be retracted** to their original positions. Press the **release button** and slide all selectors fully back. (See Illustration 3)

ILLUSTRATION 4



Country-Specific Plug Types

TO SELECT A COUNTRY-SPECIFIC PLUG TYPE:

- **EUROPEAN PLUG**
- **AUSTRALIA PLUG**
- **UK PLUG**
- **USA PLUG**

Press the **release button** on the side of the base unit. Slide the selector forward until the corresponding country-specific plug **extends and locks into place**.

ATTENTION

To reduce the risk of fire or electric shock, use only with these plug types:

EUROPEAN PLUG: 220V AC (2 round pins)

Albania, Angola, Argentina, Austria, Azores, Balearic Islands, Bangladesh, Belgium, Bolivia, Bosnia, Brazil, Bulgaria, Burkina Faso, Burundi, Cameroon, Canary Islands, Cape Verde, Central African Republic, Channel Islands, Chile, Comoros, Congo, Croatia, Democratic Republic of the Congo (Zaire), Ivory Coast, Cyprus, Denmark, Djibouti, Egypt, El Salvador, Equatorial Guinea, Eritrea, Faroe Islands, Finland, France, Gabon, Germany, Gibraltar, Greece, Greenland, Guadeloupe, Guinea, Guinea-Bissau, Hungary, Iceland, India, Indonesia, Iran, Iraq, Israel, Italy, Kazakhstan, Korea, Kuwait, Laos, Lebanon, Lithuania, Luxembourg, Macedonia, Madagascar, Madeira, Mali, Martinique, Mauritania, Mauritius, Monaco, Morocco, Mozambique, Myanmar, Nepal, Netherlands, Niger, Norway, Oman, Pakistan, Paraguay, Peru, Philippines, Poland, Portugal, Romania, Russia, Rwanda, Saint Vincent, Senegal, Somalia, Spain, Sudan, Suriname, Sweden, Switzerland, Syria, Thailand, Togo, Tunisia, Turkey, Uruguay, Vietnam, former Yugoslavia, Zambia.

AUSTRALIA PLUG: 110V AC (2 angled pins)

American Samoa, Argentina, Australia, China, El Salvador, Fiji, Guatemala, Kiribati, Nauru, New Zealand, Okinawa, Panama, Papua New Guinea, Saint Vincent, Tajikistan, Tonga, Uruguay.

USA PLUG: 110V AC (2 flat parallel pins)

American Samoa, Anguilla, Antigua, Aruba, Bahamas, Bangladesh, Barbados, Bermuda, Bolivia, Brazil, Cambodia, Canada, Cayman Islands, China (with slight variations: no holes in pins and slightly shorter blades), Colombia, Costa Rica, Cuba, Ecuador, El Salvador, Guam, Guatemala, Guyana, Haiti, Honduras, Jamaica, Japan, Laos, Lebanon, Liberia, Maldives, Mexico, Micronesia, Montserrat, Netherlands Antilles, Nicaragua, Niger, Okinawa, Panama, Peru, Philippines, Puerto Rico, Saint Vincent, Saudi Arabia, Tahiti, Taiwan, Thailand, United States, Venezuela, Vietnam, Virgin Islands (US and British), Yemen.

UK PLUG: 220V AC (3 rectangular pins)

Bahrain, Bangladesh, Belize, Botswana, Brunei, Cameroon, Channel Islands, China, Cyprus, Dominica, El Salvador, Gambia, Ghana, Gibraltar, Grenada, Guatemala, Guyana, Hong Kong, Iraq, Ireland, Isle of Man, Jordan, Kuwait, Lebanon, Macau, Malaysia, Maldives, Malta, Mauritius, Myanmar, Nigeria, Oman, Qatar, St. Kitts-Nevis, St. Lucia, St. Vincent, Saudi Arabia, Seychelles, Sierra Leone, Singapore, Tanzania, Uganda, United Arab Emirates, United Kingdom, Vietnam, Yemen, Zambia, Zimbabwe.


To retract the adapter to its original position:

Press the release button and simultaneously slide the selector all the way back so that the plug is recessed into the base of the unit.

Spare Fuse Compartment:

The unit uses only T2.5A fuses. Use a coin or similar object to unscrew the cover of the compartment. Replace the fuse, reattach the cover, and screw it tightly back into place. (See Illustration 5)

ILLUSTRATION 5



This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference.
(2) This device must accept any interference received, including interference that may cause undesired operation.

Unauthorized modifications may void FCC compliance and user authority to operate the product.

Warranty

The warranty applies when the product is used under normal conditions for which it was designed. It does **not cover**:

- Accidental damage
- Unreasonable or improper use
- Normal wear and tear
- Mishandling
- Shipping damage
- Loss of use or consequential damages
- Repairs attempted by unauthorized personnel

Disposal Notice

This symbol indicates that, at the end of its life, the product must not be disposed of with household waste (in accordance with Directive 2012/19/EU on Waste Electrical and Electronic Equipment - WEEE).
It should be taken to a designated collection center or returned to the retailer upon purchase of a new appliance. Proper disposal helps prevent environmental pollution and potential health hazards.

Safety and Compliance

- This product complies with applicable essential requirements and directives.
- The device is protected by **double or reinforced insulation**.
- Use only in **indoor, dry environments**.

Do not expose the product to moisture or liquids, as this could cause **fatal electric shock**.

IMT1088 R00